



GENERAL NOTES:
 (1) A MINIMUM OF 3" CLEARANCE FROM CABINET'S SIDES FOR PROPER VENTILATION. LEAVE ROOM TO OPEN AND CLOSE CABINET DOOR AND TO INSTALL ZONE GAS SAMPLE LINE.

						QUICK-CHECK 1 PORT POWERSAVER MANIFOLD, TYPICAL INSTALLATION		DRAWN: PJS DATE: 02/11/16	APPROVED: JVN DATE: 03/28/16
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF SOUTH-TEK SYSTEMS. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF SOUTH-TEK SYSTEMS IS PROHIBITED.						MATERIAL: FINISH: WEIGHT:		PROJECT NAME: TYPICAL INSTALLATION DRAWINGS SIZE: B	
REVISIONS: ONLY THE LATEST 3 REVISIONS WILL BE SHOWN. OLDER REVISIONS CONSOLIDATED AND FILED.						UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES WHOLE NUMBER DIM'S: ± 1 ONE DEC.: ± .2, TWO DEC.: ± .02 THREE DEC.: ± .005, ANG.: ± .05°		NUMBER: A02-QCF-PS1PM-TI SHEET: 1 OF 1 REVISION: 00	