EOX DeOxygenation Systems



FEATURES _

- Reduces oxygen in both trapped air pockets, and fill water below 1.0 ppm
- The reduction of dissolved oxygen concentration in the supply water to < 1.0 ppm helps to effectively inhibit corrosion within the wet sprinkler piping
- Effectively displaces all trapped air within a wet system with pure nitrogen
- Integrates into new or pre-existing Fire Protection Systems
- Fully pneumatic no electrical required



UNIT DETAILS

	DeOx-DX-1M	DeOx DX-3M
Part Number		
	DeOx-FPS-1M	DeOx-FPS-3M
Dimensions		
A (Cabinet Width)	20.0"	42.0"
B (Width)	37.75"	71.5"
C (Depth)	18.02"	20.1"
D (Height)	52.06"	56.0"
Unit Weight	105 lbs.	360 lbs.
Unit Details		
Fill Time	1,000 gal. per hour	3,000 gal. per hour
Output	16GPM of deoxygenated water @ < 1.0 ppm	48 GPM of deoxygenated water @ < 1.0 ppm
Electrical	No electrical required	
Working Pressure	Up to 85 PSI	
Warranty	One Year ¹	

1. Per manufacturer's terms and conditions.



Contact: FireProtection@SouthTekSystems.com | (888) 526-6284