



PRODUCT NUMBERING SYSTEM

A050V060-1230FPN

HORSEPOWER	TANK ORIENTATION	TANK SIZE	PHASE	VOLTAGE	STANDARD OPTIONS
050: 5 HP	V: Vertical H: Horizontal	060: 60 Gal	1: Single 3: Three	230/208 460	FP: Fully Packaged Includes: - Aftercooler - Automatic Tank Drain - Installation Kit N: Custom Configuration



- ✓ Nitrogen feed compressor designed to fill largest dry sprinkler system to capacity within 30 minutes
- ✓ Appropriate for single or multiple-valve systems
- ✓ Aftercooler, pneumatic tank drain, & installation kit
- ✓ Large oil sight glass, liquid filled gauge, & full synthetic oil included
- ✓ 1-year warranty included
- ✓ 3-year extended warranty available
- ✓ ETL Listed: Conforms to UL 1450 & CSA C22.2 No. 68-92

UNIT SPECIFICATIONS					FULLY PACKAGED FEATURES			ACCESSORIES AVAILABLE	
HORSEPOWER		5			▪ OVERSIZED AFTERCOOLERS • Remove over 60% of water vapor, humidity, or moisture. ▪ ENERGY SAVING PNEUMATIC AUTOMATIC TANK DRAIN • Drains condensate with zero air loss every time the compressor shuts off. • Prevents valves from fouling and reduces corrosion. ▪ INCLUDES INSTALLATION KIT • 4 mounting pads • 4 anchor bolts • 12" steel braided flex hose				Automatic Air Maintenance Device Part: CAMD1 Pack of 16: CAMD1-16PK
TANK SIZE		60 Gallon							3-Year Extended Warranty Kit (K28) Part: AX-K28
DIMENSIONS (LxDxH)		V: 30" x 21" x 73" H: 52" x 23" x 47"							1/2" x 12" Stainless Steel Flex Hose Part: DT 1005 H
SHIPPING WEIGHT		400 lbs.							1/2" x 30" Stainless Steel Flex Hose Part: DT 3005 H
PUMP SPECIFICATIONS									
STAGE		2							Synthetic Compressor Oil Part: LU 1082 GAL/LU 1082 QT
ACFM @ 175 PSI		14.25							
PUMP		2 Cylinder Aluminum							
PUMP RPM		1260							
MAIN BEARINGS		50,000 Hour							
OIL		Full Synthetic							
ELECTRICAL SPECIFICATIONS					SYSTEM SIZE		PSI	GAL	
MOTOR RPM		1745			PRE-ACTION		10	4700	
PHASE/VOLTS	FULL LOAD AMPS	BREAKER SIZE (A)	WIRE SIZE (AWG)			LOW PRESSURE		18	2611
			25'	50'	75'	STANDARD PRESSURE		40	1175
1/230	25.6	40	6	6	4				
3/230	14.6	25	10	10	8				
3/460	7.28	15	12	12	10				

A050V060.N